

PRODUCT CODE: PAF-1017

PRODUCT NAME: CleanSpace™ Full Face Mask Spectacle Kit



Description

The CleanSpace Full Face Mask Spectacle Kit (PAF-1017) is designed to allow prescription lenses to be used with the Full Face Mask without compromising the face seal. The frame is fully adjustable for all face sizes, wide frames to fit large lenses for peripheral vision; The frame is engineered to provide stability during vigorous activity and is easy to fit and adjust.

Approvals

Compatible with the CleanSpace Full Face Mask (PAF-1014)

Standard

AS/NZS1716: 2012
EN 12942

Classification

PAPR-P3

Features:

- Designed for comfort over long periods
- Allows sweating and breathability
- Easy to wash and quick drying
- Designed for long wear in harsh environments
- Easy and quick replacement

Specifications and materials

- Weight: 150g
- Dimensions: 70mm x150mm x 70mm
- Cleaning: Lukewarm water and mild detergent (neutral pH 6 – 8). Do not use solvents (turpentine or acetone), hot water, bleaching or chemical agents.
- Storage: –10°C to +55°C (–4°F to +131°F) at <90% relative humidity. Store away from direct sunlight, water, grease and oil.

Suitable Applications

Welding, Woodworking, Manufacturing, Smelting, Construction, Recycling Plants, Emergency Services, Mining, Agriculture, Processing Plants, Grinding, DIY, etc.

Training

Online training available with verification for compliance purposes.
Contact sales@paftec.com.

Limitations

CleanSpace respirators are air filtering, fan assisted positive pressure masks and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use the CleanSpace in IDLH atmospheres, to protect against gases/vapours that cannot be filtered, or in Oxygen enriched or deficient atmospheres.