



CleanSpace™ EX Filter Adaptor for large case filters (intrinsically safe)



PRODUCT CODE	PAF-0078
PRODUCT NAME	CleanSpace EX Filter Adaptor for large case filters (intrinsically safe)
DESCRIPTION	<p>CleanSpace EX Filter Adaptors are specifically designed to complete the CleanSpace EX (intrinsically safe) System when using CleanSpace large case filters. The Power Unit filter cover is removed and replaced with the Filter Adaptor. The large case filters are then clipped into place.</p> <p>IMPORTANT: When selecting a CleanSpace Filter please consult a Health and Safety specialist for advice on the appropriate respiratory equipment and filter use.</p>
APPROVALS	<p>Standard & Classification NIOSH Approved ETL Intrinsically safe</p>
FEATURES	<ul style="list-style-type: none">• Suitable for use with all CleanSpace large case filters.• Easy and quickly fitted and removed from the Power Unit.
SPECIFICATIONS	<p>Weight: 105 g Dimensions: 180mm x 100mm x 80mm</p>
MATERIALS	Plastic Casing (Electrically Conductive) Silicone Seal Steel Fasteners Stainless Steel Springs
USE & STORAGE CONDITIONS	<ul style="list-style-type: none">• Use temperature range: -10°C to +45°C (14°F to +113°F) at < 90% relative humidity• Storage conditions: +10°C to +30°C (+50°F to +86°F) at < 75% relative humidity• Store away from direct sunlight, grease and oil
APPLICATIONS	<p>Suitable for environments which require respiratory protection against airborne biohazards, particulates and dust.</p> <p>Examples: Mining, blasting, grinding, drilling, or crushing. Tunnelling, excavation, rock and mineral handling.</p>
LIMITATIONS	<p>CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace respirators in immediately dangerous to life or health (IDLH) atmospheres, to protect against gases/vapours that cannot be filtered or in oxygen enriched or deficient atmospheres.</p>
EDUCATION	Contact sales@cleanspacetechnology.com or visit the CleanSpace website for details.
WARRANTY	Visit https://cleanspacetechnology.com/warranty/ to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

Australia (Head Office): +61 2 8436 4000 | sales@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPEACEUSA.COM

