



CleanSpace™ WORK Half Mask (inc. Fabric Head Harness)



PRODUCT CODE	CS3003WORK (Small), CS3004WORK (Medium), CS3005WORK (Large)
PRODUCT NAME	CleanSpace WORK Half Mask (inc. Fabric Head Harness)
DESCRIPTION	<p>A CleanSpace WORK half mask (including a CleanSpace fabric head harness) is designed for use with the CleanSpace WORK power unit (CS3001WORK).</p> <p>A CleanSpace WORK half mask is made of soft silicone that readily moulds to the face and does not cause allergic dermatitis. The clips quickly and securely attaches the CleanSpace Work half mask to the power unit.</p> <p>The CleanSpace fabric head harness attaches to connection points on the mask arms and can be removed for cleaning.</p> <p>A CleanSpace WORK half mask (including a CleanSpace fabric head harness) is NOT certified intrinsically safe.</p>
APPROVALS	<p>Standard & Classification</p> <p>NIOSH PAPR</p>
FEATURES	<ul style="list-style-type: none"> • Lightweight, comfortable and durable • Soft silicone that readily molds to the face • Available in 3 sizes - Small, Medium and Large - to facilitate a good seal and a comfortable fit • Transparent to assist with communication • Compatible with most cleaning and disinfection protocols • Easily removable exhalation valve for cleaning • Fit Test adaptor available for Quantitative Fit Testing
SPECIFICATIONS	<ul style="list-style-type: none"> • Product Weight: CS3003WORK 5.2oz (147 g), CS3004WORK 5.4oz (153 g), CS3005WORK 5.9oz(169 g) • Product Dimensions: 170mm x 130mm x 70mm (approx) • Head Harness Product Weight: 1 oz (29 g)
MATERIALS	Silicone face piece nylon mask release clips polycarbonate exhalation valve silicone leaf valve (Head Harness Materials: Polyester Elastic High Strength Silicone)

North America (Toll Free): +1 877-256-7723 (1877CLNSPCE)
ordersUSA@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPEACEUSA.COM





CLEANING, USE & STORAGE CONDITIONS

- Cleaning: warm soapy water and soft, lint-free cloth or industrial washer
- Do not use solvents, hot water, bleaching or chemical agents
- Use temperature range: -10°C to +45°C (14°F to +113°F) at < 90% relative humidity
- Storage conditions: +10°C to +30°C (+50°F to +86°F) at < 75% relative humidity
- Store away from direct sunlight, grease and oil

APPLICATIONS

Suitable for environments which require respiratory protection against airborne particulate contaminants.

Examples (use is not limited to these examples):

- Construction – Cutting and grinding concrete, stone, brickwork, steel; sanding plaster, handling cement or other fine dusts
- Woodwork – Cutting, turning or sanding timber
- Agriculture – mowing, reaping and mulching operations; processing or handling animal feeds, grain or other dusty substances
- Restoration, maintenance and cleaning

CleanSpace WORK is suitable for applications where decontamination¹ is required.

Note 1: Where decontamination is applied, use the plastic CleanSpace HALO head harness (CS3008).

LIMITATIONS

CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace WORK in environments that are immediately dangerous to life or health (IDLH), to protect against gases/vapors, or in oxygen enriched or deficient atmospheres.

CleanSpace WORK half masks are NOT suitable for intrinsically safe certified operations.

EDUCATION

Contact orderUSA@cleanspacetechnology.com or visit the [CleanSpace website](https://www.cleanspacetechnology.com) for details.

WARRANTY

Visit www.cleanspacetechnology.com/warranty to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

CleanSpace recommends filters are replaced regularly.

