



CleanSpace™ WORK Full Face Mask



PRODUCT CODE	CS3006WORK (Small), CS3007WORK (Medium/Large)
PRODUCT NAME	CleanSpace WORK Full Face Mask
DESCRIPTION	<p>A CleanSpace WORK Full Face mask is designed for use with the CleanSpace WORK (CS3001WORK) power unit. It is suited for applications where face protection and eye protection are required.</p> <p>A CleanSpace WORK Full Face mask clips to the power unit and provides respiratory, face and eye protection. It is comprised of an outer visor, inner mask and a five-point harness to evenly support the mask and power unit and provide ease of movement.</p> <p>The rear harness strap and hook is required for use with the CleanSpace WORK (CS3001WORK) System.</p>
APPROVALS	<p>Standard & Classification</p> <p>EN12942:1998+A2:2008 AS/NZS1716: 2012 AS/NZS 1337.1:2010 High Impact Resistance</p> <p>TM3 PAPR-P3</p>
FEATURES	<ul style="list-style-type: none"> • Visor: Scratch-resistant and solvent-resistant coating • Wide panoramic visor • Silicone cushion seals to the face for optimum protection and comfort • Recommended for applications where face protection and eye protection is required • Suitable for long periods of wear • Mylar speech diaphragm for clear communication • Positive pressure airflow prevents fogging • Inner mask has a unique clip-in/clip-out design and is easily removed for cleaning • Built in port and sensing ball included for full face mask fit testing • Accessories available (sold separately): Spectacle kit and visor protection tear-offs
SPECIFICATIONS	<ul style="list-style-type: none"> • Product Weight: CS3006WORK: 700 g, CS3007WORK: 725 g • Product Dimensions: 240mm x 220mm x 280mm (approx)
MATERIALS	Hard coated polycarbonate visor nylon mask clips high strength silicone harness stainless steel buckle roller silicone face seal and inner mask cushion Mylar speech diaphragm polycarbonate exhalation valve cover impact-modified reinforced polypropylene exhalation valve housing silicone O-rings

Australia (Head Office): +61 2 8436 4000 | sales@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPACETECHNOLOGY.COM





CLEANING, USE & STORAGE CONDITIONS

- Cleaning: warm soapy water and soft, lint-free cloth or industrial washer
- Do not use solvents, hot water, bleaching or chemical agents
- Use temperature range: -10°C to +45°C (14°F to +113°F) at < 90% relative humidity
- Storage conditions: +10°C to +30°C (+50°F to +86°F) at < 75% relative humidity
- Store away from direct sunlight, grease and oil

APPLICATIONS

Suitable for environments which require respiratory protection against airborne particulate contaminants and biohazards.

Examples (use is not limited to these examples):

- Construction – Cutting and grinding concrete, stone, brickwork, steel; sanding plaster, handling cement or other fine dusts
- Woodwork – Cutting, turning or sanding timber
- Agriculture – mowing, reaping and mulching operations; processing or handling animal feeds, grain or other dusty substances
- Healthcare & Laboratories – Handling Biological material, Bacteria, Spores.

When used with the CleanSpace WORK System (CS3000WORK), the CleanSpace WORK Full Face Mask is suitable for applications where decontamination showers are used.

LIMITATIONS

CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace WORK in environments that are immediately dangerous to life or health (IDLH), to protect against gases/vapours or in oxygen enriched or deficient atmospheres.

EDUCATION

Contact sales@cleanspacetechnology.com or visit the [CleanSpace website](#) for details.

WARRANTY

Visit www.cleanspacetechnology.com/warranty to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

