



CleanSpace[®] HALO Cleaning and Storage Plug



PRODUCT CODE	CS3011
PRODUCT NAME	CleanSpace Cleaning and Storage Plug
DESCRIPTION	<p>The CleanSpace HALO Cleaning and Storage Plug is designed to be used with the CleanSpace HALO (CS3001) power unit and the CleanSpace HALO WORK (CS3001WORK) power unit.</p> <p>This accessory is used to seal both bellows and filter air inlet. Please remove the filter from the CleanSpace power unit before use.</p> <p>During cleaning, all openings must be sealed. It is also recommended that all openings are sealed after cleaning and decontamination, and during storage.</p>
FEATURES	<ul style="list-style-type: none">• Clips easily into position• Facilitates a high level of cleaning• Keeps dust and moisture from entering during and after cleaning, decontamination, and storage
SPECIFICATIONS	<ul style="list-style-type: none">• Product weight: 85 g• Product dimensions: 170 mm x 50 mm x 40 mm (approximately)
MATERIALS	Polycarbonate Silicone
CLEANING, USE & STORAGE CONDITIONS	<ul style="list-style-type: none">• Cleaning: Warm water and mild detergent (neutral pH 6 - 8). Do not use solvents (turpentine or acetone), hot water, bleaching or chemical agents• Storage conditions: +10°C to +30°C (+50°F to +86°F) at < 75% relative humidity• Store away from direct sunlight, grease and oil
APPLICATIONS	<p>CleanSpace HALO Cleaning and Storage Plug is suitable for use during and after cleaning processes, decontamination, and storage.</p> <p>The CleanSpace HALO Cleaning and Storage Plug is designed to be inserted into both bellows and filter air inlet of the CleanSpace HALO Power Unit.</p>
LIMITATIONS	The plug is not a filter. Do not attempt to run the respirator with the plug fitted.
EDUCATION	Contact sales@cleanspacetechnology.com or visit the CleanSpace website for details.

Australia (Head Office): +61 2 8436 4000 | sales@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPACETECHNOLOGY.COM





WARRANTY

Visit www.cleanspacetechnology.com/warranty to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

CleanSpace recommends filters are replaced regularly.

Australia (Head Office): +61 2 8436 4000 | sales@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPACETECHNOLOGY.COM

