



CleanSpace[®] CST Full Face Mask Harness Kit (Spare)



PRODUCT CODE	CST1031
PRODUCT NAME	CleanSpace CST Full Face Mask Harness kit (Spare)
DESCRIPTION	Spare harness kit for CleanSpace Full Face Mask. Compatible with CleanSpace Full Face Masks - CST1017, CST1018, CS3006WORK and CS3007WORK.
FEATURES	<ul style="list-style-type: none"> • Five point harness with rear harness hook.
SPECIFICATIONS	Product Weight: 91g
MATERIALS	High strength silicone
USE & STORAGE CONDITIONS	<ul style="list-style-type: none"> • Use temperature range: -10°C to +45°C (14°F to +113°F) at < 90% relative humidity • Storage conditions: +10°C to +30°C (+50°F to +86°F) at < 75% relative humidity • Store away from direct sunlight, grease and oil
APPLICATIONS	Suitable for all applications that are applicable to CleanSpace CST and CleanSpace WORK Full Face Masks.
LIMITATIONS	CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace respirators in immediately dangerous to life or health (IDLH) atmospheres, to protect against gases/vapours that cannot be filtered or in oxygen enriched or deficient atmospheres.
EDUCATION	Contact sales@cleanspacetechnology.com or visit the CleanSpace website for details.
WARRANTY	Visit https://cleanspacetechnology.com/warranty/ to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

