



CleanSpace™ CST Half Mask incl. Head Harness



PRODUCT CODE	CST1034 (Small), CST1035 (Medium), CST1036 (Large)
PRODUCT NAME	CleanSpace™ CST Half Mask incl. Head Harness
DESCRIPTION	<p>A CleanSpace CST Half Mask (including a CleanSpace CST Head Harness) is designed for use with the CleanSpace CST PRO Power Unit (CST1002) and CleanSpace ULTRA Power Unit (CST1012).</p> <p>A CleanSpace CST Half Mask is made of soft silicone that readily molds to the face and does not cause allergic dermatitis. The easy-to-locate clips secure the CleanSpace CST Half Mask to the Power Unit. The CleanSpace CST Head Harness attaches easily to connection points on the mask arms and can be removed for cleaning.</p>
APPROVALS	<p>Standard & Classification NIOSH PAPR IP65 Rating - when used with CleanSpace ULTRA Power Unit (CST1012)</p>
FEATURES	<ul style="list-style-type: none"> • Lightweight, comfortable and durable • Soft silicone that readily molds to the face • Available in 3 sizes - Small, Medium and Large - to facilitate a good seal and a comfortable fit • Transparent to assist with communication • Compatible with most cleaning and disinfection protocols • Easily removable exhalation valve for cleaning • Fit Test adaptor available for CNC Quantitative Fit Testing
SPECIFICATIONS	<ul style="list-style-type: none"> • Half Mask Product Weight: CST1034:5.2 oz, CST1035:5.4 oz, CST1036:6.0 oz • Head Harness Product Weight: 1.0 oz • Assigned Protection Factor (APF): 50 (with CleanSpace CST PRO and CST ULTRA)
MATERIALS	<p>Silicone Nylon Polycarbonate (exhalation valve assembly) (Head Harness Materials: High Density Polyethylene Nylon High Strength Silicone)</p>
CLEANING, USE & STORAGE CONDITIONS	<ul style="list-style-type: none"> • Cleaning: warm soapy water and soft, lint-free cloth or industrial washer • Use temperature range: -10°C to +45°C (14°F to +113°F) at < 90% relative humidity • Storage conditions: +10°C to +30°C (+50°F to +86°F) at < 75% relative humidity • Store away from direct sunlight, grease and oil

Australia (Head Office): +61 2 8436 4000 | sales@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPEACEUSA.COM





APPLICATIONS

Examples: Mining, Welding, Manufacturing, Smelting, Construction, Recycling Plants, Emergency Service, Agriculture, Processing Plants, Grinding.

The CleanSpace ULTRA system (CST1011) with the CleanSpace CST Half Mask (including CleanSpace CST Head Harness) is suitable for chemical applications where decontamination showers are used.

LIMITATIONS

CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace respirators in immediately dangerous to life or health (IDLH) atmospheres, to protect against gases/vapors that cannot be filtered or in oxygen enriched or deficient atmospheres.

EDUCATION

Contact sales@cleanspacetechnology.com or visit the [CleanSpace website](#) for details.

WARRANTY

Visit www.cleanspacetechnology.com/warranty/ to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

