



CleanSpace™ Fabric Head Harness



PRODUCT CODE	CST1037
PRODUCT NAME	CleanSpace Fabric Head Harness
DESCRIPTION	<p>The CleanSpace fabric head harness (CST1037) is specifically designed to aid in supporting the power unit for optimal comfort. It is designed to be used with the CleanSpace WORK (CS3020WORK) System.</p> <p>The CleanSpace fabric head harness attaches easily to connection points on the mask arms. The rear strap of the harness hooks directly onto the power unit for comfortable weight distribution.</p> <p>The CleanSpace fabric head harness is NOT certified intrinsically safe.</p> <p><i>NOTE: The CleanSpace fabric head harness is packaged with the CleanSpace WORK half mask - (Small, Medium and Large) - so is not required to be purchased separately. Please use this product code for the purpose of ordering additional items only.</i></p>
APPROVALS	<p>Standard & Classification</p> <p>NIOSH PAPR</p> <p>The CleanSpace fabric head harness is certified for use with CleanSpace WORK power unit (CS3001WORK).</p>
FEATURES	<ul style="list-style-type: none"> • Designed for comfort over long periods • Attaches securely to half mask and power unit • All 3 straps are adjustable to fit various head shapes • Fabric material is comfortable to wear under welding helmets and other head protection
SPECIFICATIONS	<ul style="list-style-type: none"> • Product Weight: 1 oz (29 g)
MATERIALS	Polyester Elastic High Strength Silicone
CLEANING, USE & STORAGE CONDITIONS	<ul style="list-style-type: none"> • Cleaning: Warm water and mild detergent (neutral pH 6 – 8). Do not use solvents (turpentine or acetone), hot water, bleaching or chemical agents • Use temperature range: -10°C to +45°C (14°F to +113°F) at < 90% relative humidity • Storage conditions: +10°C to +30°C (+50°F to +86°F) at < 75% relative humidity • Store away from direct sunlight, grease and oil

North America (Toll Free): +1 877-256-7723 (1877CLNSPCE)
ordersUSA@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPEACEUSA.COM





APPLICATIONS

Suitable for environments which require respiratory protection against airborne particulate contaminants.

Examples (use is not limited to these examples):

- Construction – Cutting and grinding concrete, stone, brickwork, steel; sanding plaster, handling cement or other fine dusts
- Woodwork – Cutting, turning or sanding timber
- Agriculture – mowing, reaping and mulching operations; processing or handling animal feeds, grain or other dusty substances
- Restoration, maintenance and cleaning

When decontamination is required the CleanSpace fabric head harness (CST1037) is not suitable. Use the CleanSpace plastic head harness (CS3008).

LIMITATIONS

CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace WORK in environments that are immediately dangerous to life or health (IDLH), to protect against gases/vapors, or in oxygen enriched or deficient atmospheres.

EDUCATION

Contact ordersUSA@cleanspacetechnology.com or visit the [CleanSpace website](https://www.cleanspacetechnology.com) for details.

WARRANTY

Visit www.cleanspacetechnology.com/warranty to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

