



CleanSpace[®] Half Mask Fit Testing Adaptor



PRODUCT CODE	PAF-0025
PRODUCT NAME	CleanSpace Half Mask Fit Testing Adaptor
DESCRIPTION	<p>The CleanSpace Half Mask Fit Testing Adaptor is designed to be used with all CleanSpace Half Masks. The Half Mask adaptor is fitted in the front of the Half Mask to enable a Quantitative Fit Test.</p> <p>Instructions for use are provided with the adaptor.</p>
FEATURES	<ul style="list-style-type: none"> • Reuseable
SPECIFICATIONS	<ul style="list-style-type: none"> • Product Weight: 25 g • Product Dimensions: 51mm x 37mm x 21mm (approx)
MATERIALS	Aluminium Nylon O-Ring Brass Pressure Port
OPERATING / USAGE CONDITIONS	<ul style="list-style-type: none"> • Use temperature range: -10°C to +45°C (14°F to +113°F) at < 90% relative humidity
STORAGE & DISPOSAL	<ul style="list-style-type: none"> • Storage conditions: +10°C to +30°C (+50°F to +86°F) at < 75% relative humidity • Store away from direct sunlight, grease and oil • Used components may have been exposed to hazardous materials and should not be considered recyclable. Dispose of used components in line with company and local authority regulations.
CLEANING	<ul style="list-style-type: none"> • Hand wash in warm (< 50°C) soapy water and rinse¹ • Do not use solvents, hot water, bleaching or chemical agents • After cleaning allow to air dry or wipe dry with a clean lint free cloth <p>Note 1: Refer to Supplements for compatible cleaning products and industrial washing processes.</p>
LIMITATIONS	CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace respirators in immediately dangerous to life or health (IDLH) atmospheres, to protect against gases/vapours that cannot be filtered or in oxygen enriched or deficient atmospheres.
EDUCATION	Contact sales@cleanspacetechnology.com or visit the CleanSpace website for details.
WARRANTY	Visit www.cleanspacetechnology.com/warranty to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

