



CleanSpace™ Pre-Filter for Standard Particulate Filter (10/Pk)



Note: Image shows pre-filter in front of particulate filter.

PRODUCT CODE	PAF-0036
PRODUCT NAME	CleanSpace Pre-Filter for Standard Particulate Filter (10/Pk)
DESCRIPTION	<p>The CleanSpace Pre-Filter is suitable for use with the CleanSpace Standard Particulate P3 TM3 P SL R Filter for protection against airborne particulate (dust, mists and fumes). The Pre-Filter is designed to remove course particles and enhance the life of the Particulate P3 filter. The Pre-Filter should be changed after each use.</p> <p>Note: The CleanSpace Pre-Filter is compitable with CleanSpace EX (PAF-0060), CleanSpace ULTRA (PAF-0070), and CleanSpaec2 (PAF-0034).</p> <p>IMPORTANT: When selecting a CleanSpace Filter please consult a Health and Safety specialist for advice on the appropriate respiratory equipment and filter use.</p>
FEATURES	<ul style="list-style-type: none"> • Easy and quickly fitted and removed from the power unit • Sold in Pack of 10 pre-filters • Enhance the life of the Particulate P3 filter
SPECIFICATIONS	<p>Product Weight: average 50g</p> <p>Product Dimensions: 170mm x 40mm x 70mm</p>
MATERIALS	Spun polymer fibres
USE & STORAGE CONDITIONS	<ul style="list-style-type: none"> • Use temperature range: -10°C to +45°C (14°F to +113°F) at < 90% relative humidity • Storage conditions: +10°C to +30°C (+50°F to +86°F) at < 75% relative humidity • Store away from direct sunlight, grease and oil • Packaged Shelf life: 5 years from manufacturing date • Only to be used with CleanSpace Filters • These filters are not water proof and should be replaced if in contact with water
APPLICATIONS	Suitable for Mining, Welding, Manufacturing, Smelting, Construction, Recycling Plants, Emergency Services, Agriculture, Processing Plants, Grinding. Refer to Filter Selection Table for more details.
LIMITATIONS	CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace respirators in immediately dangerous to life or health (IDLH) atmospheres, to protect against gases/vapours that cannot be filtered or in oxygen enriched or deficient atmospheres.
EDUCATION	Contact sales@cleanspacetechnology.com or visit the CleanSpace website for details.

Australia (Head Office): +61 2 8436 4000 | sales@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPACETECHNOLOGY.COM





WARRANTY

Visit <https://cleanspacetechnology.com/warranty/> to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

Australia (Head Office): +61 2 8436 4000 | sales@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPACETECHNOLOGY.COM

