



CleanSpace[®] Particulate Pre-Filter Coverall



PRODUCT CODE	PAF-0058
PRODUCT NAME	CleanSpace Particulate Pre-Filter Coverall
DESCRIPTION	<p>The CleanSpace Particulate Pre-Filter Coverall is a disposable cover that protects the CleanSpace power unit. It is also designed to remove coarse particles and provide limited protection against splashes (e.g. water, paint, cement, etc.).</p> <p>The coverall is designed to be used with the full range of CleanSpace respirators (fitted with standard or high capacity filters). For large case filters in the CleanSpace PAF range continue to use the CleanSpace Particulate Pre-Filter Coverall for large case filters (PAF-0049, PAF-0057).</p> <p>The Particulate Pre-Filter Coverall should be changed after each use.</p> <p>IMPORTANT: When selecting a CleanSpace filter please consult a Health and Safety specialist for advice on the appropriate respiratory equipment and filter use.</p>
FEATURES	<ul style="list-style-type: none"> • Easy to fit and quick to remove from the power unit • Extends the life of the CleanSpace particulate standard P3 TM3 filter • One time use only
SPECIFICATIONS	<ul style="list-style-type: none"> • Product Weight: 5 g • Sold in a pack of 20
MATERIALS	Spun polymer fibres
USE & STORAGE CONDITIONS	<ul style="list-style-type: none"> • Particulate Pre-Filter Coveralls are not waterproof and should be replaced if they come into contact with water. • Use temperature range: -10°C to +45°C (14°F to +113°F) at < 90% relative humidity • Storage conditions: +10°C to +30°C (+50°F to +86°F) at < 75% relative humidity • Store away from direct sunlight, grease and oil
APPLICATIONS	<p>Suitable for environments which require respiratory protection against airborne particulate contaminants and biohazards.</p> <p>Examples (use is not limited to these examples):</p> <ul style="list-style-type: none"> • Construction – Cutting and grinding concrete, stone, brickwork, steel; sanding plaster, handling cement or other fine dusts

Australia (Head Office): +61 2 8436 4000 | sales@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPACETECHNOLOGY.COM





- Woodwork – Cutting, turning or sanding timber
- Agriculture – mowing, reaping and mulching operations; processing or handling animal feeds, grain or other dusty substances
- Healthcare & Laboratories – Handling Biological material, Bacteria, Spores.

The CleanSpace particulate pre-filter coverall is suitable for applications where decontamination showers are used but must be disposed of after each shower.

LIMITATIONS

CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace HALO WORK in environments that are immediately dangerous to life or health (IDLH), to protect against gases/vapours, or in oxygen enriched or deficient atmospheres

EDUCATION

Contact sales@cleanspacetechnology.com or visit the [CleanSpace website](#) for details.

WARRANTY

Visit www.cleanspacetechnology.com/warranty to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

CleanSpace recommends filters are replaced regularly.

