



CleanSpace[®] NIOSH HE + Nuisance Filter



PRODUCT CODE	PAF-1108
PRODUCT NAME	CleanSpace NIOSH HE + Nuisance Filter
DESCRIPTION	<p>CleanSpace Nuisance Odor Filters are a NIOSH approved particulate filter. The layer of activated multi-gas carbon provides nuisance relief for organic vapors (OV), acid gases (AG) and ammonia.</p> <p>These filters are suitable for nuisance level exposure not exceeding OSHA PEL.</p> <p>CleanSpace Nuisance Odor filters are compatible with the CleanSpace EX, CleanSpace ULTRA and CleanSpace2 Power Units.</p> <p>IMPORTANT: When selecting a CleanSpace Filter consult a Health and Safety specialist for advice on the appropriate respiratory equipment and filter use</p>
APPROVALS	<p>Standard & Classification</p> <p>NIOSH</p>
FEATURES	<ul style="list-style-type: none"> For applications with multi-gas at levels not exceeding OSHA PEL, includes organic vapors (OV), acid gases (AG) and ammonia. Used in high water applications or for decontamination (CleanSpace EX and CleanSpace ULTRA only)
SPECIFICATIONS	<ul style="list-style-type: none"> Product Weight: 1.1 oz Approved (HE) High Efficiency filtration performance: > 99.97% filtration efficiency for particulates
MATERIALS	Borosilicate microfiber filter media Activated Carbon ABS (acrylonitrile butadiene styrene) Plastic Casing Silicone Seal
OPERATING / USAGE CONDITIONS	<ul style="list-style-type: none"> Use temperature range: 14°F to +113°F at < 90% relative humidity
STORAGE & DISPOSAL	<ul style="list-style-type: none"> Storage conditions: +50°F to +86°F at < 75% relative humidity Store away from direct sunlight, grease and oil Used components may have been exposed to hazardous materials and should not be considered recyclable. Dispose of used components in line with company and local authority regulations

North America (Toll Free): +1 877-256-7723 (1877CLNSPCE) | ordersUSA@cleanspacetechnology.com

Uncontrolled if downloaded or printed from the internet.

WWW.CLEANSPACEUSA.COM





- Packaged Shelf life: 5 years from manufacturing date

APPLICATIONS

Post Fire Investigation, Welding, Waste and Water management, Construction, Paper Manufacturing, Maintenance & Cleaning, Pharmaceutical, Laboratories, Animal Facilities, Police Investigation & Forensics and Animal & Food Processing.

Note: When used with formaldehyde odors the filter should be replaced at the end of each work shift.
For further information please submit an inquiry at: www.cleanspacetechnology.com/technical-advice/

LIMITATIONS

CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace respirators in immediately dangerous to life or health (IDLH) atmospheres, to protect against gases/vapors that cannot be filtered or in oxygen enriched or deficient atmospheres.

EDUCATION

Contact ordersUSA@cleanspacetechnology.com or visit the [CleanSpace Website](#) for details.

WARRANTY

Visit www.cleanspacetechnology.com/warranty to read important Warranty information and complete the Warranty Registration Online Form for CleanSpace Products. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

